

Please lubricate bushings on filling machine and bottom up fill on a monthly basis.

Use a light machine oil (Pneumatic tool oil)

Festo-Pneumatics Oil OFSW-32 Oil or similar





Please lubricate bushings on filling machine and bottom up fill on a monthly basis.

